



f-stop always starts in lower case, even if it's on the beginning of the sentence. Even the brands website is "www.fstopgear.com", the brand itself is called only "f-stop".

Correct example: *"f-stop designs and manufactures modular camera packs..."*

## PACK FEATURES

- The main body material used on both the Mountain and Urban Series is a 440D Rip Stop Nylon - a material that is made using a special reinforcing technique that makes them resistant to tearing and ripping.
- The packs feature a DWR coating. This makes them weatherproof but NOT waterproof. They are made out of waterproof materials, but since they are assembled using a sewing technique, they are not waterproof.
- Key critical points feature weatherproof zippers and/or zipper garages as well as zipper protecting lids
- All Mountain Series and Ultralight Series backpacks feature an internal aluminum frame (removable) for increased stability and comfort
- All packs feature a variety of adjustment points for the carry harness to best possible "custom fit" the pack to the user's anatomy
- Access to the main compartment is possible through the back panel of the pack to provide security in transport and sketchy environments (theft protection as opening is against users back)
- The camera packs are modular, they fit up to a certain size of ICU, depending on the size of the pack
- ICU = Internal Camera Unit, you can also stack ICU's on top of each other
- In the pack there are ICU attachment points that are used to optionally secure the ICU inside the pack (two on bottom left/right sides, two on top left/right sides)
- There are 9 ICU's in total providing different depth and heights for any situation and pack combination



## FURTHER FEATURES

- The elastic pull cords on the front can be used to strap a small tripod, ice axes or hiking/skiing poles.
- The bottom of the pack is made out of Hypalon material which is famous for high resistance to the extremes an outdoor environment provides
- There are a variety of mounting/attachment points (Gate-Keeper Loops) around the bags for adding additional gear on the outside of the pack & extending the volume of it
- Gate-Keepers are an accessory available separately

## LOADING THE PACK

### Step 1

- Open the ICU and insert your gear inside
    - a. Secure the gear with the elastic bands
    - b. Don't close the ICU
    - c. Take the top lid of the ICU and fold it behind
    - d. Once you have the ICU set up, open the top zipper of the pack and insert the ICU inside the pack
- (The opening of the ICU should face the back of the camera pack - towards the back panel)

### Step 2

- Secure the ICU with the Velcro straps.
- Close the camera pack and put down the flaps of the zipper

### Step 3

- Open the back panel of the pack and the gear should be at your disposal

